

PuREPower

15.0 Lite

USER MANUAL



USER MANUAL

Table Of Contents

1. About This Manual.....	1
1.1 Purpose.....	1
1.2 Scope.....	1
2. Safety Instructions.....	2
3. Introduction.....	2
3.1 Features.....	2
3.2 Basic System Architecture.....	2
3.3 Product Overview.....	3
3.3.1 Pouch LCD color screen	3
3.3.2 Back panel.....	3
4. Installation.....	4
4.1 Unpacking And Inspection	4
4.2 Installing the PuREPower	4
4.3 Thres-phase mode	5
4.4 Requirements for cables and ring circuit breakers.....	5
4.5 AC input & output connection.....	6
4.6 PuREPower Connecting Line Diagram.....	7
5. Operation.....	8
5.1 Power ON/OFF.....	8
5.1.1 Steps to start up	8
5.2 LCD display icon	8
5.2.1 Home Screen	8
5.3 Touch screen flow chart.....	10
5.4 Touch screen operation instructions.....	10
5.4.1 Touch screen home screen content.....	10
5.4.2 System settings menu.....	12
6. Solar of Things Wi-Fi Connectivity.....	12
6.1 Wi-Fi Solar Of Things App Connectivity Procedure.....	17
6.1.1 APP Download	17
6.1.2 Registered Account	17
6.1.3 Add Wi-Fi Datalogger.....	18
6.1.4 Wireless Router Connection.....	18
6.1.5 Wireless Router Connection.....	19
6.1.6 Network Setting	19
6.1.7 Monitoring Data	20

7. Wi-Fi Connectivity Procedure.....	21
7.1 Smart BMS App Download Procedure.....	21
7.2 Smart BMS App Operation.....	22
7.3 Wi-Fi Connectivity Procedure.....	23
7.4 PuREPower SoH Monitor Using Wi-Fi	25
8. LCD Display Icons	26
8.1 Function and alarm description.....	26
8.1.1 Fault Reference Code	26
8.2 Warning Indicator	27
8.3 Fault Code Display.....	27
8.4 Dry Contact Signal	28
8.5 Troubleshooting Guide	29
9. WHAT TO DO IN CASE OF AN EMERGENCY.....	31
10. Warranty Policy.....	31
11. Do's and Don'ts	32
12 . Instructions For Servicing.....	32
13 . Disposal and Recycling Information.....	26
13.1 Environmentally Safe Disposal Practic.....	33
13.2 Battery Disposal and Recycling	33
14. Legal Disclaimers.....	33
14.1 Limitation of Liability	33
14.2. Misuse Disclaimer	34
14.3. Third-Party Component Exclusions	34
14.4. Governing Law and Jurisdiction	34
15 . Technical datasheet	35
16.PuREPower WARRANTY REGISTRATION CARD.....	36
17.QR codes for PuREPower Installation Guidelines.....	36

1 About This Manual

1.1 Purpose

This manual describes the installation, operation, and troubleshooting of this unit (PuREPower). Please read this manual carefully before installation and operation. Keep the manual for future reference.

1.2 Scope

This manual provides safety and installation guidelines as well as information on tools and wiring.

2 Safety Instructions

WARNING: This chapter contains important safety and operating instructions. Read and keep this manual for future reference.

1. Before using the PuREPower, carefully read all instructions and cautionary markings provided throughout this manual.

2. Do not attempt to disassemble the unit. If service or repair is needed, contact a qualified service center. Incorrect reassembly may result in an electric shock or fire.

3. To minimize the risk of electric shock, disconnect all wiring before performing any maintenance or cleaning. Simply turning off the unit does not eliminate this risk.

4. **CAUTION** - The PuREPower UNIT must be installed only by qualified electrical personnel.

5. NEVER charge a frozen PuREPower.

6. For best performance, ensure that cable sizing follows the specified requirements mentioned in this manual. Proper cable selection is critical for the safe and efficient operation of the PuREPower unit.

7. **Caution** – Use extreme care when working with metal tools around the PuREPower unit. Dropping a metal object could result in a short circuit, sparking, or battery damage, potentially leading to fire or explosion.

8. **AC Disconnection** – Always follow the prescribed installation procedure when disconnecting the AC power. Refer to the INSTALLATION section of this manual for detailed instructions.

9. **Grounding Instructions** – This PuREPower unit must be connected to a permanent grounding system. Ensure compliance with all applicable local electrical codes and regulations during installation.

10. **Warning** – Servicing of this device should be performed only by qualified service personnel. If issues persist after consulting the troubleshooting guide, return the PuREPower unit to the authorized dealer or service center for further assistance.

11. NEVER cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.

12. Stabilizer must be installed if each of phase voltage is not with in the range of 210 V to 250 V

3. Introduction

This multi-functional All in One PuREPower unit integrates an inverter, charger, and battery into a compact, wall-mounted design, providing uninterrupted power support. It features a comprehensive touch LCD color screen with user-friendly buttons, allowing easy configuration of settings such as battery charging current, AC/solar charging priority, and acceptable input voltage tailored to various applications.


3.1 Features

- Round Trip Efficiency - 97.0%
- Dry contacts for load control
- Nano PCM for Thermal
- Time of Use
- Automatic Transfer Switch (ATS)
- Synchronize @ Solar, DG & Grid
- Pure Sine Wave
- Smart & Connected (App, Wi-Fi and Bluetooth)
- Predictive & Cloud AI
- Safe & Secure
- 10+ Years Life
- Grid-Tied Enabled

3.2 Basic System Architecture


The following illustration shows the various power input sources (Grid/Generator , PV Modules) through which PuREPower draws, stores power and provides energy backup. It also showcases the various applications that can be powered using PuREPower.

PuREPower is capable of powering a wide range of apartment/home and motor related appliances like Elevators,Mixer Grinders, Ovens, Refrigerators, Air Conditioners , lighting fixtures etc. Also high power appliances like drill machine, grinding machines etc.,




3.3 Product Overview

3.3.1 Touch LCD color Screen



3.3.2 Back Panel



Note: The Wi-Fi signal booster antenna must be fixed on the side of the panel during installation. (if you available this port)

4 INSTALLATION

4.1 Unpacking and Inspection

Before installation, carefully inspect the PuREPower 20.O unit to ensure that no damage has occurred during shipping. Confirm that the package includes the following items:


- The PuREPower unit x 1 (Including Wheels attached to the Unit)
- Warranty Manual,

4.2 Installing the device

Before selecting the installation location, ensure proper ventilation is considered. The PuREPower unit is designed with built-in ventilation, and the fan surface is positioned near the exhaust outlet.


Please consider the following points before choosing the installation location:

- Do not install the PuREPower on or near flammable construction materials.
- To ensure adequate heat dissipation, maintain a clearance of approximately 30 cm on each side and 70 cm above the unit.
- The recommended ambient temperature range for optimal operation is -20°C to 50°C. Note that performance may decline at temperatures above 40°C.
- Ensure that surrounding objects and surfaces are positioned as illustrated in the installation diagram to support proper ventilation and allow sufficient space for cable routing and maintenance.



 SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.

4.3 Three-phase mode



Items	Description
Applicable model	PuREPower15.0 Lite
AC output phase voltage (L-N)	200-400Vac, 230Vac default

4.4 Requirements for cables and ring circuit breakers

- PV Input

Model	Cable Diameter	Max PV Input Current	Circuit Breaker Spec
PuREPower15.0 Lite	10 sq mm	3x27A	3x32A

- AC Input

Model	Output Mode	Max Current	Cable Diameter	Circuit Breaker Spec
PuREPower15.0 Lite	L1+L2+L3+N+PE	4x21.7A	4x10 sq mm	4x63A/230VAC

- AC Input


Model	Output Mode	Max Current	Cable Diameter	Circuit Breaker Spec
PuREPower15.0 Lite	L1+L2+L3+N+PE	4x21.7A	4x10 sq mm	4x63A/230VAC


Connect the phase, neutral, and ground cables in the position and order of the cables as shown in the diagram below.

4.5 AC input & output connection

PV Input, AC input, AC output,

1. Use a stripper to remove the 6-8mm insulation of the Cable
2. Fixing a ferrule at the end of the cable (ferrule needs to be prepared by the user)
3. Fixing cable lugs that supply the box at the end of the cable.as shown below





Note: If a DG is available at the site, its rated power capacity must be at least 1.5 times the rated power of the PuREPower system.

Note: In OFF-GRID conditions only, all PV strings must be properly connected to PV1, PV2, and PV3




Connect the phase, neutral, and ground cables in the position and order of the cables as shown in the diagram below.

- Before connecting the AC input and output, the circuit breaker must be disconnected to avoid the risk of electric shock and must not be operated with electricity.
- Make sure that the open circuit voltage of the PV modules connected in series does not exceed the maximum open circuit voltage of the PuREPower (the value is 500V), otherwise, the PuREPower may be damaged
- Load segregation is mandatory to ensure that the product is not over-loaded including the safety factor and the power-factor. After switching on the complete load, Confirm the performance of PuREPower and record the load values, in both grid and off grid condition. If the total load exceeds 3kVA on any Single Phase

4.7 PuREPower single line connection diagram


Single Line Diagram (SLD) of PuRPower 15.0 Lite



Note: In OFF-GRID conditions only, all PV strings must be properly connected to PV1, PV2, and PV3

5 OPERATION

5.1 Power ON/OFF



Once PuREPower has been properly installed, simply press ON/OFF switch (located beneath the LCD screen at the front of the unit) to turn ON the unit.

5.1.1 Steps to start up

Mains power on:

Connect to normal AC power, press the switch, and the system will automatically turn on. If you set AC output power priority, after waiting for a period of time, the panel will display AC mode which represents turn on the machine successfully, and then will enter the AC mode.


When the normal mains power is connected and press the power-on button then the system will automatically power on. If it is set as AC output priority, after a period of time, the panel will display the AC mode to indicate that the power-on is complete and enter the AC mode.

5.2 LCD display icon


The operation and LCD display panel shown below is located on the front panel of the PuREPower.

5.2.1 Home Screen


The touch screen LCD . The upper part of the LCD screen shows overall information about the PuREPower.



1. The absence of an icon in the center of the home screen indicates that the system is operating normally. If the gray icon and characters are displayed in the center of the main screen, it means that the PuREPower has an alarm, and the alarm information will be displayed in characters under this icon (detailed error information can be viewed in the instruction manual alarm menu). If the red icon and characters are displayed in the center of the main screen, it means that the PuREPower is faulty, and the fault information will be displayed in characters under this icon (detailed error information can be viewed in the instruction manual alarm menu).



PuREPower is over charged



PV voltage is over limitation

2. Time & Date is displayed on the top of the LCD screen.


3. PuREPower Settings icon, press the Settings button, you can enter the system Settings screen, including PuREPower .System working mode, grid settings, basic settings, advanced features, device information.

4. The main screen displays information including PV, mains, load and PuREPower battery. It also shows the direction of energy flow with arrows, equivalent power indication across all 3 phases. When approaching the limit value, the color on the panel will change from green to red, making the system information vividly displayed on the main screen.

5. Both Photovoltaic power and load power should always be positive. (when available)

6. The negative direction of the battery power supply means discharging, and the positive direction means charging.

5.3 Touch screen flow chart







5.4 Touch screen operation instructions

5.4.1 Touch screen Home screen Content

PuREPower home page	PuREPower home page
Detail Machine Type: 5548 Lcd Version: V 10.01 Inverter Type: HPVINV02 Driver Version: V 10.01 Boosting Temper: 26 °C Main Version: V 30.03 Machine Temper: 27 °C MPPT Temper: 24°C MOS Temper: 27°C IAP Status: Normal ↑ L1 ↓ Back	This page shows the PuREPower machine model,machine type, booster tube temperature, machine temperature, MPPT temperature, PuREPower board temperature, bottom program is normal, color screen version number, central control board version number, machine control board version number.
PV Page	PV data page details
Solar L1 PV Input: 0.0 V 0.0 A L1 PV Input Power: 0 W L2 PV Input: 0.0 V 0.0 A L2 PV Input Power: 0 W L3 PV Input: 0.0 V 0.0 A L3 PV input Power: 0 W Today: 2.882KWh Month: 2.8 KWh Year: 2.8KWh Total: 2.8KWh Back	This page shows the input voltage, current and power of photovoltaic solar panels in detail.It can also record today's photovoltaic power generation,this month's photovoltaic power generation,this year's photovoltaic power generation, and the total photovoltaic power generation.

Battery page	Battery details page
Battery Battery Voltage: USE BMS COM Function: OFF Battery Voltage: 49.7 V Charge Current: 0 A Discharge Current: 0 A L1 Bus Voltage: 348 V L2 Bus Voltage: 348 V L3 Bus Voltage: 349 V Li Battery Active: OFF BAT BMS Back	This page shows the battery type, BMS current communication status, battery voltage, BAT charging current, BAT discharge current and BUS voltage in detail and Li Battery Active.
BMS page	BMS details page
BMS BMS 485 Protocol: NULL SOC: 100 % Charge Current: 0.0 A Discharge Current: 0.0 A BMS Temper: 0.0 °C Discharge Limit Voltage: 0.0 V Charge Limit Voltage: 0.0 V Charge Limit Current: 100.0 A Li Battery Active: BAT BMS Back	This page displays the BMS current usage protocol, BMS current SOC value, BMS charging current, BMS discharge current BMS temperature, BMS discharge limit voltage, BMS charge limit voltage, BMS charge limit current in detail.
Load page	Load detail page
Load L1 Output: 230.0 V 50.0 Hz L1 Load Percent: 0 % L1 Power: 0 W 0 VA L2 Output: 230.0 V 49.9 Hz L2 Load Percent: 0 % L2 Power: 0 W 0 VA L3 Output: 230.1 V 49.9 Hz L3 Load Percent: 0 % L3 Power: 0 W 0 VA Back	This page displays the output mode, output voltage, output frequency, inductive current, active power, and reactive power in detail.
Mains page	Mains details page
AC Input L1 Frequency: 0.0 Hz L1 Input Voltage: 0.0 V L1 Ac Input Power: 0 W L2 Frequency: 0.0 Hz L2 Input Voltage: 0.0 V L2 Ac Input Power: 0 W L3 Frequency: 0.0 Hz L3 Input Voltage: 0.0 V L3 Ac Input Power: 0 W Back	This page displays the frequency, input voltage, and power of the grid


5.4.2 System Settings menu

System Settings menu	System Settings menu page
	This is the system Settings page, including battery Settings, system working mode, battery Settings, mains Settings, charging Settings, basic Settings, advanced functions, device information
Basic Settings menu	Basic Settings menu page
	This page can be set PuREPower voltage: 220/230/240V(default 230V) PuREPower frequency: 50/60HZ(default 50HZ) Alarm Control: ON/OFF Over Load Bypass: ON/OFF Over Load Restart: ON/OFF
	This page can be set MIP Cut Off Buz: ON/OFF Over Temp Restart: ON/OFF Auto Back Menu: ON/OFF
System working mode setting menu	System working mode setting menu page
	This page can be set ECO function: Under the battery model, when the load is low, the system will temporarily stop. Output priority: Output source priority option.


System working mode setting menu System Work Mode <table><thead><tr><th>Setting Parameter</th><th>Current Value</th><th>Set Value</th><th></th><th></th></tr></thead><tbody><tr><td>ECO</td><td>OFF</td><td>OFF</td><td>☒</td><td rowspan="5">Work Mode page 1/1</td></tr><tr><td>Output Priority</td><td>SUB</td><td>SUB</td><td>☒</td></tr><tr><td>Output TYPE</td><td>PAL</td><td>PAL</td><td>☒</td></tr><tr><td>Clear Generation</td><td>OFF</td><td>OFF</td><td>☒</td></tr><tr><td>Reset Factory Setting</td><td>OFF</td><td>OFF</td><td>☒</td></tr></tbody></table>	Setting Parameter	Current Value	Set Value			ECO	OFF	OFF	☒	Work Mode page 1/1	Output Priority	SUB	SUB	☒	Output TYPE	PAL	PAL	☒	Clear Generation	OFF	OFF	☒	Reset Factory Setting	OFF	OFF	☒	System working mode setting menu page SUB: Solar energy as the first priority for the load, if the solar energy is not enough to supply all connected loads, the utility grid energy will supply the load at the same time. Solar power is the first priority, providing power for the load output source priority selection. SBU: If the solar energy is not enough to supply all the connected loads, the battery energy will supply the loads simultaneously. The mains supply power to the load only when the battery voltage drops to a low level warning voltage or when the solar and battery are insufficient. Output TYPE:SIG/PAL/3P1/3P2/3P3 Remove the power generation capacity: tick the check box and click "YES". Clear Generation: OFF/ON Reset Factory Setting: To restore the default values, tick the check box and click "YES".
Setting Parameter	Current Value	Set Value																									
ECO	OFF	OFF	☒	Work Mode page 1/1																							
Output Priority	SUB	SUB	☒																								
Output TYPE	PAL	PAL	☒																								
Clear Generation	OFF	OFF	☒																								
Reset Factory Setting	OFF	OFF	☒																								
Main grid Settings menu Grid Setting <table><thead><tr><th>Setting Parameter</th><th>Current Value</th><th>Set Value</th><th></th><th></th></tr></thead><tbody><tr><td>Input Voltage Range</td><td>APL</td><td>APL</td><td>☒</td><td rowspan="4">Grid Setting page 1/2</td></tr><tr><td>Grid-Connected Regulation</td><td>India</td><td>India</td><td>☒</td></tr><tr><td>Grid Feed Enable</td><td>OFF</td><td>OFF</td><td>☒</td></tr><tr><td>Grid Feed Current</td><td>10A</td><td>10A</td><td>☒</td></tr></tbody></table>	Setting Parameter	Current Value	Set Value			Input Voltage Range	APL	APL	☒	Grid Setting page 1/2	Grid-Connected Regulation	India	India	☒	Grid Feed Enable	OFF	OFF	☒	Grid Feed Current	10A	10A	☒	Main grid Settings menu page This page can be set Input Voltage Range: APL/UPS Grid-Connected Regulation: India/ Germen/SouthAmerica Grid Feed Enable: Disable / Enable Grid Feed Current: Default 20A				
Setting Parameter	Current Value	Set Value																									
Input Voltage Range	APL	APL	☒	Grid Setting page 1/2																							
Grid-Connected Regulation	India	India	☒																								
Grid Feed Enable	OFF	OFF	☒																								
Grid Feed Current	10A	10A	☒																								
Grid Setting <table><thead><tr><th>Setting Parameter</th><th>Current Value</th><th>Set Value</th><th></th><th></th></tr></thead><tbody><tr><td>AC CHA Open Time</td><td>0:00</td><td>0:00</td><td>☒</td><td rowspan="2">Grid Setting page 2/2</td></tr><tr><td>AC CHA Stop Time</td><td>0:00</td><td>0:00</td><td>☒</td></tr></tbody></table>	Setting Parameter	Current Value	Set Value			AC CHA Open Time	0:00	0:00	☒	Grid Setting page 2/2	AC CHA Stop Time	0:00	0:00	☒	This page can be set AC CHA Open Time: The value ranges from 0 to 23. AC CHA Stop Time: The value ranges from 0 to 23.												
Setting Parameter	Current Value	Set Value																									
AC CHA Open Time	0:00	0:00	☒	Grid Setting page 2/2																							
AC CHA Stop Time	0:00	0:00	☒																								

Advanced Function Setting Parameter Current Value Set Value Output Open Time 0:00 ◀ 0:00 ☒ Output Stop Time 0:00 ◀ 0:00 ☒ Adv page 3/3 This page can be set Output Open Time: The value ranges from 0 to 23. Output Stop Time: The value ranges from 0 to 23..	
Device information setting menu	Device information setting menu page
Device Info System Time:0000-00-00 00:09 2000 Year 0 Month 0 Day 0 H 9 M 0 S Back Light: RGB Switch: ☒ ☒ ON This page can be set System time: year/month/day/hour/minute /second. Back Light: From dark to light. RGB Switch: ON/OFF	

Smart Datalogger connecting position and LED indication



6. Solar of Things Wi-Fi Connectivity



6.1 Wi-Fi Solar Of Things App Connectivity Procedure

1. Wireless Wi-Fi Distribution Network

7.1.1 APP Download


Step 1 : Scan the QR, click on the link to download the app.

Step 2 : Or scan the QR code on the given Wi-Fi device.

Step 3 : Search in the Play Store/iOS to download the APP named "Solar of Things" for download.

6.1.2 Registered Account


On the App home page, click the "Sign Up" button, fill in the relevant information according to the prompt, and complete the registration.




6.1.3 Supporting Network And Adding Device

6.1.4 Wi-Fi Collector Connection Router

After the PWR(Power) light indicator on the device/collector is on, turn on the mobile phone Bluetooth and Solar of Things App, click the "Wi-Fi Configuration" button to enter the "Searching" page, and the page will automatically display the near by Bluetooth device



- Select the device/collector that needs to be distributed, enter the matching webpage, and click the search icon. You can choose the Wi-Fi hotspot name.




6.1.5 Add Device

Step 1:


- Enter the homepage of the APP, click "+" in the upper right corner, enter the device to add the page, then the mobile phone app close to the device, and the app scan the device automatically

- After scanning to the device, select the ID that is consistent with the ID of the collector tag, and click "Add" to relevant data fill then click finish.

Note : Please confirm the collector ID before scanning. If the ID information as not found on the surface of the dongle label, you can view the ID on the matching page



Step 2 : "Manually Add", complete the adding device according to the interface prompt, manual output collector ID, name, and other information




Step 3 :

Scan Add", scan the QR code ID number of the collector film, and use the device with the corresponding collector

6.1.6 Collector Fault Diagnosis and Indicator Light Judgment

6.1.7 Collector Fault Diagnosis

1) After the device distribution network is completed or fails, you can make a failure diagnosis by clicking on the upper right "Diagnose".



6.1.8 Collector Indicator Status

16. PWR (power indicator light):
On: normal power supply
Off: abnormal power supply
17. COM (serial port transmission indicator):
Off: Number of data interactions
Off for 0.3 seconds, on for 0.9 seconds : serial output data
Off for 0.3 seconds, on for 0.3 seconds : serial port receiving data
Two-way receiving and receiving
18. Net (network status indicator):
Off for 0.3 seconds, on for 3 seconds : STA mode connects the upper router
Off for 0.3 seconds, on for 0.3 seconds : STA is not connected to the upper router
19. SRV (server connection indicator)
On: Has been connected to the server
Off: Uninterrupted to the server

7. Wi-Fi connectivity procedure :

7.1 PURE BMS App Download Procedure

Search and download PURE BMS App from Play Store (Android) or App Store (iOS).



Step 1:

- Ensure that Bluetooth and Wi-Fi are switched on in your mobile device.
- Make sure to have the Wi-Fi router password handy for later use.
- Verify that the Wi-Fi network is operating on a 2.4GHz frequency.



Step 2:


- Open either the Play Store (Android) or App Store (iOS).
- Search for PURE BMS and install the app. Once installed, open the app.



7.2 PURE BMS App Operation



Step 3:

Click on Agree, then select "Remote Monitoring."



Step 4:



- Enter the provided email and password, then click Login.(if you are a new login please click on immediate registration)
- Choose the "Parallel" mode. During this process, allow all pop-up access requests.



7.3 Wi-Fi Connectivity Procedure :


Step 5 :

- In the PURE BMS app, click on the "Connecting Devices +" icon in the upper-right corner and select "Wi-Fi Devices."




Step 6 :

- Select the desired Wi-Fi device name, then click Next Step.
- Enter your Wi-Fi router password and proceed to the next step.




Step 7 :

- After successfully connecting to the device, you should see the "Binding Device" message. Click Save to complete the process.




Step 8 :

- The network and device allocation process will now be complete. On the “Connect Device” page, the corresponding Wi-Fi module will appear. If the status shows “Online,”you can select the PuREPower device and open it, as shown in the figures below.



7.4 PuREPower SoH Monitor Using Wi-Fi

Now we can monitor PuREPower State of Health(SoH) like SoC%(State of Charge), Voltage, Current, No.Cycles, and Temperature etc.



8. LCD Display Icons

8.1 Function and alarm description

- Fault : The PuREPower enters the fault mode, the red LED light is always on and the LCD displays the fault code.

8.1.1 Fault Reference Code

Fault Code	Fault Event	Icon on
01	Fan is locked when PuREPower is off.	
02	Over over-temperature or NTC is not connected with.	
03	Battery voltage is too high	
04	Battery voltage is too low	
05	Output short-circuits or over-temperature is detected by internal converter components.	
06	Output voltage is too high	
07	Over load time out	
08	Bus voltage is too high	
09	Bus soft start failed	
51	Overcurrent's or surges	
52	Bus voltage is too low	
53	PuREPower soft start failed	
55	Over DC voltage in AC output	
57	Current sensor failed	
58	Output voltage is too low	
59	PV voltage is over limitation	

Alarm: The red LED flashes, and the LCD displays an alarm code, the PuREPower does not enter the failure mode

8.2 Warning Indicator

Warning Code	Warning Event	Audible Alarm
01	Fan is locked when PuREPower is on	Beep three times every second
02	Over temperature	None
03	Battery is over-charged	Beep once every second
04	Low battery	Beep once every second
07	Overload	Beep once every 0.5 second
10	Output power derating	Beep twice every 3 seconds
15	PV energy is low.	Beep twice every 3 seconds
16	High AC input (>280VAC) during BUS soft start	None
E9	Battery equalization	None
bP	Battery is not connected	None

8.3 Fault Code Display

Fault Code	Description
60	If PuREPower status is not allowed to charge and discharge after the communication between the inverter and battery is successful, it will show code 60 to stop charging and discharging battery
61	Communication lost
69	If PuREPower status is not allowed to charge after the communication between the inverter and battery is successful, it will show code 69 to stop charging battery

Fault Code	Description
70	If PuREPower status must to charged after the communication between the inverter and battery is successful, it will show code 70 to charge the PuREPower.
71	If PuREPower status is not allowed to discharge after the communication between the inverter and battery is successful, it will show code 71 to stop discharge battery
80-82	Problem occurs parallel status, cables, parallel boards connection

8.4 Dry Contact Signal

There is one dry contact (3A/250VAC) available on the rear panel. It could be used to deliver signal to external device when battery voltage reaches warning level.



Dry contact port

Unit Status	Condition		Dry Contact Port: NC & C	Dry Contact Port: NC & C
Power OFF	Unit is OFF and no output is powered		Close	Open
Power ON	Output is powered from battery or solar	Normal mode Battery voltage < Low DC warning voltage	Open	Close
		Battery voltage > Float charging voltage	Close	Open
		Solar first mode Battery voltage < Solar to AC voltage	Open	Close
		Battery voltage > AC to DC voltage	Close	Open

8.5 Troubleshooting Guide

This section provides guidance on identifying and resolving common issues encountered with the unit. Refer to the problem, symptoms, possible causes, and recommended corrective actions below

Problem	LCD/LED/Buzzer	Explanation/Possible Cause	What To Do
Unit shuts down automatically during startup process	LCD/LEDs and buzzer will be active for 3 seconds and then complete off.	The battery voltage is too low	1. Re-charge battery. 2. Replace battery.
No response after power on	No indication	1. The battery voltage is far too low 2. Internal fuse tripped	1. Contact repair center for replacing the fuse. 2. Re-charge battery. 3. Replace battery. Check if AC breaker is tripped and AC wiring is connected well.
Mains exist but the unit works in battery mode.	The battery image lights up, but there is no response from the mains image	Input protector is tripped	
		Insufficient quality of AC power. (utility or Generator)	1. Check if AC wires are too thin and/or too long. 2. Check if generator (if applied) is working well or if input voltage range setting is correct. (UP-->Appliance).
		Set 'Solar First' as the priority of output source	Change output source priority to Utility first.
When the unit is turned on, internal relay is switched on and off repeatedly.	Battery is disconnected	Battery is disconnected	Check if battery wires are connected well.
Buzzer beeps continuously and red LED is on.	Fault code 07	Overload error. The PuREPower is overloaded 105% and time is up.If PV input voltage is higher than specification, the output power will be derated.	Reduce the connected load by switching off some equipment. Reduce the number of PV modules in series or the connected load

Buzzer beeps continuously and red LED is on.	Fault code 05	Output short circuited	Check if wiring is connected well and remove abnormal load.
	Fault code 02	Temperature internal converter component is over 120°C.	Check whether the airflow of the unit is blocked or whether the ambient temperature is too high.
	Fault code 03	Battery is over-charged The battery voltage is too high.	Return to repair center. Check if spec and quantity of batteries meet requirements
	Fault code 01	Fan fault	Replace the fan
	Fault code 06/58	Output abnormal (PuREPower voltage below 190Vac or higher than 260Vac)	1. Reduce the connected load. 2. Return to repair center.
	Fault code 08/09/53/57	Internal components failed.	Return to repair center.
	Fault code 51	Over current or surge	Restart the unit
	Fault code 52	Bus voltage is too low	Restart the unit; if the error happens again, please return to repair center.
	Fault code 58	Output voltage is unbalanced.	Return to repair center.
	Fault code 59	PV input voltage is beyond the specification	Reduce the number of PV modules in series.
	Fault code 61	Communication lost	Restart the unit
	Fault code 80-82	CAN fault	Restart the unit / Problem occurs parallel status, cables, parallel boards connection

9. WHAT TO DO IN CASE OF AN EMERGENCY

If PuREPower is making unusual noises:

- Turn off all PuREPower, then turn off the AC breaker to PuREPower.
- Turn off the PuREPower integrated DC MCB.
- Ensure that nothing is blocking the air intake or in the fan
- In all cases, once the situation is stable, contact the Certified Installer who installed the system..

10. Warranty Policy :

PuREPower provides a warranty of 60 months for the battery and 36 months for both the inverter and protection board (BMS), beginning from the date of purchase. The warranty that the battery will retain at least 70% of its capacity for the duration of the warranty period. All other components are covered for one year warranty

S No	Item	Base Warranty
1	Battery Pack	5 Years
2	BMS	3 Years
3	Integrated Mother-board	3 Years
4	All Electrical Items & Consumables	1 Years
5	Cloud AI Support	5 Years
6	Firmware Upgrades	3 Years
7	Remote Data Monitoring	3 Years
8	Cloud Alerts	3 Years
9	Deep Discharge Coverage	Applicable only if 24x7 Wi-Fi Available and Limited to 5 Years

The repair or replacement of the PuREPower is subject to the terms and conditions mentioned in the battery warranty policy.

The Warranty Stands Void in Case of the Following Cases :

- Warranty claims will not be accepted under any circumstances if the damage or defect arises from the following causes. These conditions fall outside the scope of PuR Energy Ltd warranty obligations.
- Damage caused by insufficient ventilation or restricted airflow, resulting in reduced cooling performance, is not covered under warranty.
- Warranty is void if the product is installed improperly or by an installer who is not accredited by PuR Energy Ltd.
- Any defects arising from incorrect or non-compliant use, installation, commissioning, start-up, or operation of the product are not eligible for warranty claims.
- Damage caused by improper wiring, including electrical arcing or harm to the product or its components, is excluded from warranty coverage.
- Mishandling or misuse of the product by the installer or end-user, such as dropping the product during installation, will void the warranty.

- Damage resulting from force majeure events—such as lightning strikes, overvoltage, storms, fire, or flooding—is not covered under this warranty.
- Any damage incurred during incorrect or careless transportation of the product is not covered by the warranty. Unauthorized repair, modification, or reinstallation of the product will void all warranty obligations
- Water ingress, corrosive gas damage, or installation in dirty environments, causing particles to affect performance — is not covered under this warranty.
- If PuREPower Unit is idle/ inoperative condition for more than 6 months can lead to void in warranty terms

11.Do's and Don'ts

Do's

- Ensure installation is performed by authorized personnel
- Verify proper grounding and secure electrical connections.
- Use the app or cloud platform to monitor performance and receive alerts regularly.
- Ensure the unit is placed in a well-ventilated, dry area and away from direct sunlight to prevent overheating.
- Report faults immediately and ensure repairs are performed by authorized technicians
- If you plan to leave for a long time (≥ 30 days), you should comply with the following requirement to ensure that the SOC system of the battery is above 60% and the power switch is kept OFF. Keep in mind that the system should restart to charge the battery within 90 days.

Don'ts :

- Do not connect loads exceeding the rated capacity of the system.
- Do not attempt to repair or modify the unit without consulting authorized service personnel.
- Do not expose the unit to water, direct sunlight, corrosive chemicals, or physical shocks.
- Do not ignore fault alerts or fail to address them promptly.
- Do not remove the Wi-Fi module or disable the cloud monitoring setup.

12 . Instructions For Servicing

When the PuREPower is not functioning or for any query follow below instructions:

- Connect to the installer/dealer for immediate assistance or call toll-free No:1800 212 6440
- Our service team will guide you whether PuREPower to be sent back for repair or can be serviced near your location.

- The on-site visit charges are applicable as per the standards. In case of any warranty component replacements, only components are covered under warranty.
- PuREPower installation charges are applicable.
- Do not remove the Wi-Fi module or disable the cloud monitoring setup.

13. Disposal and Recycling Information

13.1 Environmentally Safe Disposal Practices

To minimize environmental impact and ensure the safe disposal of this PuREPower, users are advised not to dispose of the product with regular household waste. Instead, it should be handed over to an authorized electronic waste collection centre or returned to the manufacturer for proper recycling or disposal. Improper disposal may lead to environmental hazards or pose health risks.

This product is designed in compliance with applicable environmental standards and should be disposed of by local laws and regulations governing electronic waste.

13.2 Battery Disposal and Recycling

- If the PuREPower includes a built-in or external battery, please note:
- Batteries contain hazardous substances and must be disposed of carefully to avoid soil and water contamination.
- Do not incinerate, dismantle, or puncture the battery.
- Used batteries must be returned to the authorized collection centers or recyclers approved under the E-Waste (Management) Rules, 2022, as notified by the Ministry of Environment, Forest and Climate Change, Government of India.
- For lithium-ion batteries, users should consult local battery recycling programs or contact the manufacturer for take-back options.
- By disposing of this product and its components responsibly, you contribute to environmental conservation and support sustainable waste management practices.

14. Legal Disclaimers

14.1 Limitation of Liability

- The manufacturer and its authorized distributors shall not be liable for any direct, indirect, incidental, consequential, or special damages arising out of the use or inability to use this product, even if advised of the possibility of such damages. This includes, but is not limited to, damages for loss of profits, data, business interruption, or personal injury.
- The total liability of the manufacturer, whether in contract, tort, or otherwise, shall in no case exceed the purchase price of the product.

14.2. Misuse Disclaimer

This product is designed to be used strictly in accordance with the instructions provided in this manual. The manufacturer shall not be held responsible for any damage, injury, malfunction, or loss caused due to:

- Improper installation
- Unauthorized modification
- Operation under abnormal conditions (e.g., excessive load, extreme temperatures, or humidity)
- Use of incompatible or substandard accessories
- Failure to perform recommended maintenance

Any such use shall immediately void the warranty and the user shall bear all responsibility for resulting consequences.

14.3. Third-Party Component Exclusions

- This PuREPower may require integration with third-party components such as external batteries, solar panels, wiring, or circuit protection devices. The manufacturer disclaims all liability for performance issues, malfunctions, or damage resulting from the use of:
- Non-recommended or substandard third-party components
- Improper installation of such components
- Lack of compatibility or certification

The warranty shall not extend to any issues arising from the failure or malfunction of third-party accessories not supplied or recommended by the manufacturer

14.4. Governing Law and Jurisdiction

- This product and any disputes arising out of or in connection with its purchase, usage, warranty, or interpretation of this manual shall be governed by and construed in accordance with the laws of India.
- All disputes, claims, or proceedings arising out of this product shall be subject to the exclusive jurisdiction of the competent courts at Hyderabad, Telangana, and no other court shall have jurisdiction in such matters

Model		PuREPower15.0 Lite
Input	Input Sources	3-Phase
	Rated Input Voltage	3 x 415 VAC
	Voltage Range	380-440 VAC
	Frequency	50 Hz
Output	Output Rating Power	15000 W
	Nominal Rating Power	11300 W
	Output Voltage	415VAC $\pm$ 5%
	Waveform	Pure Sine Wave
	Transfer Time	10 ms
	Surge Power	24000VA
	Switching Modes	On Grid /Off Grid/Hybrid
	Efficiency (Peak)	~~ 94%
Battery	Max. Continuous Discharging Current	90A X3
	Battery Voltage	54.3 V
	Max. Continuous charging Current	60 A
SOLAR CHARGER & AC CHARGER	PV Charging Mode	Triple MPPT
	MAX PV Input Power	3X8500W
	MPPT Tracking Range	60~450VDC
	MAX. PV Input Voltage	450VDC
	MAX. Input current	3X 27 A
	MAX AC/ PV Charging Current	360A
Display	LCD interface	Operating mode/load/etc
General Data	Dimension, W x D x H (mm)	(510 x 524 x 1131)
	Net Weight (kg)	150 Kgs
	Cooling concept	Advanced Nano PCM
	Communication Interface	BMS, Dry-contact, CAN, Bluetooth, Wifi, AI Cloud

16. PuREPower WARRANTY REGISTRATION CARD

CUSTOMER NAME: _____

ADDRESS 1: _____

_____ CITY _____

STATE _____ PIN CODE _____

MOBILE NO: +91 _____

MAIL ID: _____

PuREPower MODEL : _____ PuREPower S.NO: _____

SOLD ON: DD _____ MM _____ YY _____ DEALER CODE: _____

STAMP & SIGNATURE DEALER

CUSTOMER SIGNATURE

17. QR codes for PuREPower Installation Guidelines

After completing the installation of PuREPower, scan the below provided QR code and complete all the mandatory steps for successful installation and warranty registration.



For I&C Warranty registration link



For Installation videos



For Safety Protocol

Note: Filling out the form linked via the QR code is mandatory. Failure to provide installation details will result in the product's warranty being deemed null and void.



PuR Energy Limited

H. No 10-38/2, Survey no 424/AA3, Beside Arya College of Pharmacy Near IIT Hyderabad, Kandi
Village, Sangareddy, Pin Code: 502285
Customer Care: 1800 212 6440