

PuREPower 30.0 -

User Manual



Table Of Contents

1. About This Manual.....	1
1.1 Purpose.....	1
1.2 Scope.....	1
2. Safety Instructions.....	2
3. Introduction.....	2
3.1 Features.....	2
3.2 Basic System Architecture.....	2
3.3 Product Overview.....	3
3.3.1 LED color screens.....	3
3.3.2 Back panel.....	3
4. Installation.....	4
4.1 Unpacking And Inspection.....	4
4.2 Installing the PuREPower.....	4
4.3 Three-phase mode.....	5
4.4 Requirements for cables and ring circuit breakers.....	5
4.5 AC input & output connection.....	6
4.6 PV Connection.....	7
4.7 PV Module Selection Guidelines.....	8
4.7.1 PV Module Wire Connection.....	8
4.7.2 PV Module MC4 connectors.....	8
4.8 PV Module Specifications.....	8
4.9 PuREPower Connecting Line Diagram.....	9
5. Operation.....	11
5.1 Power ON/OFF.....	11
5.1.1 Steps to start up.....	12
5.2 LED indicators.....	12
5.2.1 Home Screen.....	12
5.3 Function Keys.....	12
6 . PURE BMS Wi-Fi Connectivity Procedure	13
6.1 PURE BMS App Download Procedure	13
6.2 PURE BMS APP Operation	14
6.3 Wi-Fi Connectivity Procedure	15
6.4 PuREPower SoH Remote Monitor Using Wi-Fi	17
7 . Solar of Things Wi-Fi Connectivity Procedure	18
7.1 Wi-Fi to Solar of Things App Connectivity Procedure	18

7.1.1 Solar of Things App Download Procedure.....	18
7.1.2 Registration Account/Sign Up	18
7.1.3 Supporting Network and Adding Device	19
7.1.4 Wi-Fi Collector Connection Router	19
7.1.5 Add Device	21
7.1.6 Collector Fault Diagnosis and Indicator Light Judgment	21
7.1.7 Collector Fault Diagnosis	21
7.1.8 Collector Indicator Status.....	21
8. LCD Display Icons	22
8.1 Function and alarm description	23
8.1.1 Fault Reference Code	23
8.2 Warning Indicator	24
8.3 Fault Code Display	24
8.4 Dry Contact Signal	25
8.5 Troubleshooting Guide	26
9. WHAT TO DO IN CASE OF AN EMERGENCY	28
10. Warranty Policy	28
11. Do's and Don'ts	29
12. Instructions For Servicing	30
13. Disposal and Recycling Information	31
13.1 Environmentally Safe Disposal Practice	31
13.2 Battery Disposal and Recycling	31
14. Legal Disclaimers	31
14.1 Limitation of Liability	31
14.2. Misuse Disclaimer	32
14.3. Third-Party Component Exclusions	32
14.4. Governing Law and Jurisdiction	32
15 . Technical datasheet	33
16. PuREPower WARRANTY REGISTRATION CARD	34
17. QR codes for PuREPower Installation Guidelines	34
18. Display Settings	35

1 About This Manual

1.1 Purpose

This manual describes the installation, operation, and troubleshooting of this unit (PuREPower). Please read this manual carefully before installation and operation. Keep the manual for future reference.

1.2 Scope

This manual provides safety and installation guidelines as well as information on tools and wiring.



2 Safety Instructions

WARNING: This chapter contains important safety and operating instructions. Read and keep this manual for future reference.

1. Before using the PuREPower, carefully read all instructions and cautionary markings provided throughout this manual.

2. Do not attempt to disassemble the unit. If service or repair is needed, contact a qualified service center. Incorrect reassembly may result in an electric shock or fire.

3. To minimize the risk of electric shock, disconnect all wiring before performing any maintenance or cleaning. Simply turning off the unit does not eliminate this risk.

4. CAUTION - The PuREPower UNIT must be installed only by qualified electrical personnel.

5. NEVER charge a frozen PuREPower.

6. For best performance, ensure that cable sizing follows the specified requirements mentioned in this manual. Proper cable selection is critical for the safe and efficient operation of the PuREPower unit.

7. Caution – Use extreme care when working with metal tools around the PuREPower unit. Dropping a metal object could result in a short circuit, sparking, or battery damage, potentially leading to fire or explosion.

8. AC Disconnection – Always follow the prescribed installation procedure when disconnecting the AC power. Refer to the INSTALLATION section of this manual for detailed instructions.

9. Grounding Instructions – This PuREPower unit must be connected to a permanent grounding system. Ensure compliance with all applicable local electrical codes and regulations during installation.

10. Warning – Servicing of this device should be performed only by qualified service personnel. If issues persist after consulting the troubleshooting guide, return the PuREPower unit to the authorized dealer or service center for further assistance.

11. NEVER cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.

12. Stabilizer must be installed if each of phase voltage is not within the range of 210 V to 250 V

3. Introduction

This multi-functional All in One PuREPower unit integrates an inverter, charger, and batteries into a compact, floor-mounted design, providing uninterrupted power support. It features a comprehensive LED color screen displays with user-friendly buttons, allowing easy configuration of settings such as battery charging current, AC/solar charging priority, and acceptable input voltage tailored to various applications.


3.1 Features

- Round Trip Efficiency - 94.0%
- Pure Sine Wave
- Dry contacts for load control
- Predictive & Cloud AI
- Safe & Secure
- 10+ Years Life
- Grid-Tied Enabled
- Single Phase to 3 Phase convertibility
- Smart & Connected (App, Wi-Fi and Bluetooth)
- Nano PCM for Thermal
- Time of Use
- Scalable
- Automatic Transfer Switch (ATS)
- Synchronize @ Solar, DG & Grid

3.2 Basic System Architecture

The following illustration shows the various power input sources (Grid/Generator , PV Modules) through which PuREPower draws, stores power and provides energy backup. It also showcases the various applications that can be powered using PuREPower.

PuREPower is capable of powering a wide range of apartment/home and motor related appliances like Elevators, Mixer Grinders, Ovens, Refrigerators, Air Conditioners , lighting fixtures etc. Also high power appliances like drill machine, grinding machines etc.,




Hybrid System

3.3 Product Overview


3.3.1 LED color Screens

- 1.LED display
- 2.Status indicator
- 3.Charging indicator
- 4.Fault indicator
- 5.ESC
- 6.UP
- 7.DOWN
- 8.ENTER



3.3.2 Detail View

1. AC INPUT CONNECTION
2. AC OUTPUT CONNECTION
3. PV (SOLAR) CONNECTIONS
4. INPUT MCCB
5. CHANGEOVER
6. DC MCCB
7. COMMUNICATION PORT (R-PHASE)
8. COMMUNICATION PORT (Y-PHASE)
9. COMMUNICATION PORT (B-PHASE)
10. BMS COMMUNICATION PORT (R-PHASE)
11. BMS COMMUNICATION PORT (Y-PHASE)
12. BMS COMMUNICATION PORT (B-PHASE)
13. DRY CONTACT (R-PHASE)
14. DRY CONTACT (Y-PHASE)
15. DRY CONTACT (B-PHASE)
16. POWER ON/OFF SWITCH
17. EARTHING CONNECTION
18. P1 DISPLAY (R-PHASE)
19. P2 DISPLAY (Y-PHASE)
20. P3 DISPLAY (B-PHASE)
21. EYE BOLT (LIFTING PURPOSE)
22. DOOR LOCK HANDLE.



4 INSTALLATION

4.1 Unpacking and Inspection

Before installation, carefully inspect the PuREPower 30.0 unit to ensure that no damage has occurred during shipping. Confirm that the package includes the following items:


- The PuREPower unit x 1 (Including Wheels attached to the Unit)
- Warranty Manual card

4.2 Installing the device

Before selecting the installation location, ensure proper ventilation is considered. The PuREPower unit is designed with built-in ventilation, and the fan surface is positioned near the exhaust outlet.


Please consider the following points before choosing the installation location:

- Do not install the PuREPower on or near flammable construction materials.
- To ensure adequate heat dissipation, maintain a clearance of approximately 30 cm on each side and 70 cm above the unit.
- The recommended ambient temperature range for optimal operation is -20°C to 50°C. Note that performance may decline at temperatures above 40°C.
- Ensure that surrounding objects and surfaces are positioned as illustrated in the installation diagram to support proper ventilation and allow sufficient space for cable routing and maintenance.



⚠ SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY

4.3 Three-phase mode



Items	Description
Applicable model	PuREPower 30.0
AC output phase voltage (L-N)	200-400Vac, 230Vac default

4.4 Requirements for cables and ring circuit breakers

- PV Input

Model	Cable Diameter	Max PV Input Current	Circuit Breaker Spec
PuREPower 30.0	6 sq mm	6x18A	6x32A

- AC Input

Model	Input Mode	Max Current	Cable Diameter	Circuit Breaker Spec
PuREPower 30.0	L1+L2+L3+N+PE	26.9A	4x16 sq mm	4x63A/230VAC

- AC Output

Model	Output Mode	Max Current	Cable Diameter	Circuit Breaker Spec
PuREPower 30.0	L1+L2+L3+N+PE	26.9A	4x16 sq mm	4x63A/230VAC

NOTICE


PV Input, AC input, AC output,

1. Use a stripper to remove the 6-8mm insulation of the Cable.
2. Fixing a ferrule at the end of the cable (ferrule needs to be prepared by the user).
3. Fixing cable lugs that supply the box at the end of the cable.as shown below



4.5 AC input & output connection

Connect the phase, neutral, and ground cables in the position and order of the cables as shown in the diagram below.



DANGER :

Connect each phase, neutral, and ground cables in the position and order of the cables as shown in the diagram below.

- Before connecting the AC input and output, the circuit breaker must be disconnected to avoid the risk of electric shock and must not be operated with electricity.
- Make sure that the open circuit voltage of the PV modules connected in series does not exceed the maximum open circuit voltage of the PuREPower (the value is 450VDC), otherwise, the PuREPower may be damaged.
- Load segregation is mandatory to ensure that the product is not over-loaded including the safety factor and the power-factor. After switching on the complete load, Confirm the performance of PuREPower and record the load values, in both grid and off grid condition (If the total load exceeds 8kVA on any Single Phase)

4.6 PV Connection

Before connecting the PuREPower unit to PV modules, a DCDB must be installed between the PV modules and the PuREPower. This is essential for system safety and maintenance purposes.

- All wiring must be performed by qualified personnel only.
- To ensure safe and efficient system operation, it is crucial to use appropriately rated cables for PV module connections.
- Using the correct cable size minimizes the risk of overheating or electrical hazards.
- Please refer to the recommended cable specifications below for proper sizing.

4.7 PV Module Selection Guidelines


When selecting suitable PV modules for use with the PuREPower unit, please ensure the following requirements are met :

- The open circuit voltage (Voc) of the PV module(s) must not exceed the maximum allowable PV array open circuit voltage specified for the PuREPower.
- For optimal system performance, the total supply voltage of the PV module(s) should fall within the recommended PV input voltage range of the PuREPower.
- If a single PV module does not meet the voltage requirement, multiple PV modules must be connected in series to achieve the appropriate voltage level.

Failure to follow these guidelines may lead to reduced efficiency or potential system damage.

4.7.1 PV Module Wire Connection

Check the polarity of the wires from the PV modules and the PV input connectors. Connect the positive (+) wire to the positive (+) terminal of the PV input connector, and the negative (-) wire to the negative (-) terminal of the PV input connector.



4.7.2 PV Module MC4 connectors





4.8 PV Module Specifications

Model	PuREPower 30 .0
PV Charging Mode	6 MPPTs
MAX.PV Input Power	6*5500W
MPPT Tracking Range	90 ~ 450VDC
Best Voltage	300~400V
MAX.PV Input Voltage	60~ 450 VDC

Model	PuREPower 30 .0
PV MAX input Current	18Ax6
PV MAX Charging Current	450A
MAX AC Charging Current	450A
MAX Charging Current	450A


4.9 Single Line Connection Diagram





5 OPERATION

5.1 Power ON/OFF



Once PuREPower has been properly installed, simply press ON/OFF switch (located at the back side of the unit) to turn ON the unit.

5.1.1 Steps to start up

Mains Power ON:


Connect to normal AC power, press the switch, and the system will automatically turn on. If you set AC output power priority(Changeover MCB in Battery mode), after waiting for a period of time, the panel will display AC mode which represents turn on the machine successfully, and then will enter the AC mode.

When the normal mains power is connected and press the power-on button then the system will automatically power on. If it is set as AC output priority(Changeover MCB in Battery mode), after a period of time, the display panels would display the AC mode to indicate that the power-on is complete and enter the AC mode.

5.2 Operation and Display Panels

The operation and LED display panels(P1,P2 and P3) shown below are located on the back panel of the PuREPower and LEDs display indicators are shown in the table below. It includes three indicators, four function keys, and an LED displays that provides details on the operating status, as well as input and output power information.

- 1.LED display
- 2.Status indicator
- 3.Charging indicator
- 4.Fault indicator
- 5.ESC
- 6.UP
- 7.DOWN
- 8.ENTER



5.2.1 LED indicators

LED Indicator		Messages	
	Green	Solid On	The output is powered by the utility in Line mode.
		Flashing	Output is powered by battery or PV in battery mode.
	Orange	Solid On	The unit is fully charged.
		Flashing	The unit is charging.
	Red	Solid On	The fault occurs in the PuREPower.
		Flashing	A warning condition occurs in the PuREPower.

5.3 Function Keys

Function Keys	Description
ESC	To exit setting mode
UP	To go to the previous selection
DOWN	To go to the next selection
ENTER	To confirm the selection in setting mode or enter setting mode


6. Wi-Fi connectivity procedure :

6.1 PURE BMS App Download Procedure

Search and download PURE BMS App from Play Store (Android) or App Store (iOS).


Step 1:

- Ensure that Bluetooth and Wi-Fi are switched on in your mobile device.
- Make sure to have the Wi-Fi router password handy for later use.
- Verify that the Wi-Fi network is operating on a 2.4GHz frequency.



Step 2 :


- Open either the Play Store (Android) or App Store (iOS).
- Search for PURE BMS and install the app. Once installed, open the app.



6.2 PURE BMS App


Operation Step 3 :

Click on Agree, then select "Remote Monitoring."



Step 4 :


- Enter the provided email and password, then click Login.(if you are a new login please click on immediate registration)
- Choose the "Parallel" mode. During this process, allow all pop-up access requests.



6.3 Wi-Fi Connectivity Procedure :


Step 5 :

- In the PURE BMS app, click on the "Connecting Devices +" icon in the upper-right corner and select "Wi-Fi Devices."




Step 6 :

- Select the desired Wi-Fi device name, then click Next Step.
- Enter your Wi-Fi router password and proceed to the next step.




Step 7 :

- After successfully connecting to the device, you should see the “Binding Device” message. Click Save to complete the process.




Step 8 :

- The network and device allocation process will now be complete. On the “Connect Device” page, the corresponding Wi-Fi module will appear. If the status shows “Online,” you can select the PuREPower device and open it, as shown in the figures below.




6.4 PuREPower SoH Remote Monitor Using Wi-Fi

Now we can monitor PuREPower State of Health(SoH) like SoC%(State of Charge), Voltage, Current, No.Cycles, and Temperature etc.



7. Solar of Things Wi-Fi Connectivity



7.1 Wi-Fi Solar Of Things App Connectivity Procedure

1. Wireless Wi-Fi Distribution Network

7.1.1 APP Download


Step 1 : Scan the QR, click on the link to download the app.

Step 2 : Or scan the QR code on the given Wi-Fi device.

Step 3 : Search in the Play Store/iOS to download the APP named "Solar of Things" for download.

7.1.2 Registered Account


On the App home page, click the "Sign Up" button, fill in the relevant information according to the prompt, and complete the registration.




7.1.3 Supporting Network And Adding Device

7.1.4 Wi-Fi Collector Connection Router

After the PWR(Power) light indicator on the device/collector is on, turn on the mobile phone Bluetooth and Solar of Things App, click the "Wi-Fi Configuration" button to enter the "Searching" page, and the page will automatically display the near by Bluetooth device



- Select the device/collector that needs to be distributed, enter the matching webpage, and click the search icon. You can choose the Wi-Fi hotspot name.




7.1.5 Add Device

Step 1:


- Enter the homepage of the APP, click "+" in the upper right corner, enter the device to add the page, then the mobile phone app close to the device, and the app scan the device automatically

- After scanning to the device, select the ID that is consistent with the ID of the collector tag, and click "Add" to relevant data fill then click finish.

Note : Please confirm the collector ID before scanning. If the ID information as not found on the surface of the dongle label, you can view the ID on the matching page



Step 2 : "Manually Add", complete the adding device according to the interface prompt, manual output collector ID, name, and other information




Step 3 :

"Scan Add", scan the QR code ID number of the collector film, and use the device with the corresponding collector

7.1.6 Collector Fault Diagnosis and Indicator Light Judgment

7.1.7 Collector Fault Diagnosis

1) After the device distribution network is completed or fails, you can make a failure diagnosis by clicking on the upper right "Diagnose".



7.1.8 Collector Indicator Status

16. PWR (power indicator light):
On: normal power supply
Off: abnormal power supply
17. COM (serial port transmission indicator):
Off: Number of data interactions
Off for 0.3 seconds, on for 0.9 seconds : serial output data
Off for 0.3 seconds, on for 0.3 seconds : serial port receiving data
On: Two-way receiving and receiving
18. Net (network status indicator):
Off for 0.3 seconds, on for 3 seconds : STA mode connects the upper router
Off for 0.3 seconds, on for 0.3 seconds : STA is not connected to the upper router
19. SRV (server connection indicator)
On: Has been connected to the server Off.
Uninterrupted to the server

8. LCD Display Icons

Icon	Function
Input source information	
AC	Indicates the AC input
PV1	Indicates the 1" PV panel input
PV2	Indicates the 2 PV panel input and so on
Left digital display information	
	Indicate input voltage, input frequency, battery voltage, V1 voltage, PV2 voltage, charger current
The middle digital display information	
	Indicates the setting programs.
	Indicates the warning and fault codes. Warning: Flashing 88 with warning code Fault: display 88 with fault code
The right digital display information	
	Indicate the output voltage, output frequency, load percent, load VA, load W, PV1 charger power, PV2 charger power, DC discharging current.
Battery information	
	Indicates battery level by 0-24%, 25-49%, 50-74% and 75-100% and charging status.
	1 bar Indicates 25% charge, 2 bars indicate 50%, 3 bars indicate 75%, and 4 bars indicate a fully charged battery at 100%
Load information	
OVERLOAD	Indicates overload
	Indicates the load level by 0-24%, 25-50%, 50-74%, and 75-100%.
	0%-25% 25%~50% 50%-75% 75%~100%
Mode operation information	
	Indicates the unit connects to the mains.

 PV1	Indicates the unit connects to the 1" PV panel
	Indicates the solar charger is working
	Indicates the DC/AC PuREPower circuit is working.
Mode operation information	
	Indicates the unit alarm is disabled.

8.1 Function and alarm description

Fault : The PuREPower enters the fault mode, the red LED light is always on and the LCD displays the fault code.


8.1.1 Fault Reference Code

Fault Code	Fault Event	Icon on
01	Fan is locked when PuREPower is off.	
02	Over-temperature or NTC is not connected well.	
03	Battery voltage is too high.	
04	Battery voltage is too low.	
05	Output short-circuits or over-temperature is detected by internal converter components.	
06	Output voltage is too high.	
07	Over load time out.	
08	Bus voltage is too high	
09	Bus soft start failed	
51	Overcurrent's or surges	
52	Bus voltage is too low	
53	PuREPower soft start failed	
55	Over DC voltage in AC output	

57	Current sensor failed	
58	Output voltage is too low	
59	PV voltage is over limitation	

Alarm: The red LED flashes, and the LCD displays an alarm code, the PuREPower does not enter the failure mode

8.2 Warning Indicator

Warning Code	Warning Event	Audible Alarm	Icon Flashing
01	Fan is locked when PuREPower is on	Beep three times every second	
02	Over temperature	None	
03	Battery is over-charged	Beep once every second	
04	Low battery	Beep once every second	
07	Overload	Beep once every 0.5 second	 OVER LOAD
10	Output power derating	Beep twice every 3 seconds	
15	PV energy is low.	Beep twice every 3 seconds	
16	High AC input (>280VAC) during BUS soft start	None	
Eq	Battery equalization	None	
bp	Battery is not connected	None	

8.3 Fault Code Display

Fault Code	Fault Event	Icon On
60	Power feedback protection	
61	Communication lost	

71	Firmware version inconsistent	71
72	Current sharing fault	72
81	Host loss	81
82	Synchronization loss	82
83	Battery voltage detected different	83
84	AC input voltage and frequency are detected differently	84
85	AC input voltage and frequency are detected differently	85
86	AC output mode setting is different	86

8.4 Dry Contact Signal

There is one dry contact (3A/250VAC) available on the rear panel. It could be used to deliver signal to external device when battery voltage reaches warning level.



Dry contact port

Unit Status	Condition	Dry Contact Port:NC& C	Dry Contact Port: NC & C
Power OFF	Unit is OFF and no output is powered	Close	Open
Power ON	Output is powered from battery or solar	Normal mode Battery voltage < Low DC warning voltage	Open
		Battery voltage > Float charging voltage	Close
		Solar first mode Battery voltage < Solar to AC voltage	Open
		Battery voltage > AC to DC voltage	Close

8.5 Troubleshooting Guide

This section provides guidance on identifying and resolving common issues encountered with the unit. Refer to the problem, symptoms, possible causes, and recommended corrective actions below

Problem	LCD/LED/Buzzer	Explanation/Possible Cause	What To Do
Unit shuts down automatically during startup process	LCD/LEDs and buzzer will be active for 3 seconds and then complete off.	The battery voltage is too low	Re-charge battery. Replace battery.
No response after power on.	No indication	The battery voltage is far too low Internal fuse tripped	contact repair center for replacing the fuse. Re-charge battery. Replace battery.
Mains exist but the unit works in battery mode.	Input voltage is displayed as 0 on the LCD and green LED is flashing.	Input protector is tripped	Check if AC breaker is tripped and AC wiring is connected well.
	Green LED is flashing	Insufficient quality of AC power. (utility or Generator)	Check if AC wires are too thin and/or too long. Check if generator (if applied) is working well or if input voltage range setting is correct.
When the unit is turned on, internal relay is switched on and off repeatedly.	LCD display and LEDs are flashing	Battery is disconnected.	Check if battery wires are connected well.
Buzzer beeps continuously and red LED is on.	Fault code 07	Overload error. The PuREPower is overloaded 105% and time is up. If PV input voltage is higher than specification, the output power will be derated.	Reduce the connected load by switching off some equipment. Reduce the number of PV modules in series or the connected load.

Buzzer beeps continuously and red LED is on.	Fault code 05	Output short circuited	Check if wiring is connected well and remove abnormal load.
	Fault code 02	Temperature internal converter component is over 120°C.	Check whether the airflow of the unit is blocked or whether the ambient temperature is too high.
	Fault code 03	Battery is over-charged. The battery voltage is too high.	Return to repair center. Check if spec and quantity of batteries meet requirements
	Fault code 01	Fan fault	Replace the fan.
	Fault code 06/58	Output abnormal (PuREPower voltage below 190Vac or higher than 260Vac)	Reduce the connected load. Return to repair center.
	Fault code 08/09/53/57	Internal components failed.	Return to repair center.
	Fault code 51	Over current or surge.	Restart the unit
	Fault code 52	Bus voltage is too low	Restart the unit; if the error happens again, please return to repair center.
	Fault code 58	Output voltage is unbalanced.	Return to repair center.
	Fault code 59	PV input voltage is beyond the specification	Reduce the number of PV modules in series.

9. WHAT TO DO IN CASE OF AN EMERGENCY

If PuREPower is making unusual noises:

- Turn off all PuREPower, then turn off the AC breaker to PuREPower.
- Turn off the PuREPower integrated DC MCB.
- Ensure that nothing is blocking the air intake or in the fan
- In all cases, once the situation is stable, contact the Certified Installer who installed the system.

10. Warranty Policy :

PuREPower provides a warranty of 60 months for the battery and 36 months for both the inverter and protection board (BMS), beginning from the date of purchase. The warranty that the battery will retain at least 70% of its capacity for the duration of the warranty period. All other components are covered for one year warranty.

S No	Item	Base Warranty
1	Battery Pack	5 Years
2	BMS	3 Years
3	Integrated Mother-board	3 Years
4	All Electrical Items & Consumables	1 Years
5	Cloud AI Support	5 Years
6	Firmware Upgrades	3 Years
7	Remote Data Monitoring	3 Years
8	Cloud Alerts	3 Years
9	Deep Discharge Coverage	Applicable only if 24x7 Wi-Fi Available and Limited to 5 Years

The repair or replacement of the PuREPower is subject to the terms and conditions mentioned in the battery warranty policy.

The Warranty Stands Void in Case of the Following Cases :

- Warranty claims will not be accepted under any circumstances if the damage or defect arises from the following causes. These conditions fall outside the scope of PuR Energy Ltd warranty obligations.
 - Damage caused by insufficient ventilation or restricted airflow, resulting in reduced cooling performance, is not covered under warranty.
 - Warranty is void if the product is installed improperly or by an installer who is not accredited by PuR Energy Ltd.
 - Any defects arising from incorrect or non-compliant use, installation, commissioning, start-up, or operation of the product are not eligible for warranty claims.
 - Damage caused by improper wiring, including electrical arcing or harm to the product or its components, is excluded from warranty coverage.
 - Mishandling or misuse of the product by the installer or end-user, such as dropping the product during installation, will void the warranty.

- Damage resulting from force majeure events—such as lightning strikes, overvoltage, storms, fire, or flooding—is not covered under this warranty.
- Any damage incurred during incorrect or careless transportation of the product is not covered by the warranty. Unauthorized repair, modification, or reinstallation of the product will void all warranty obligations
- Water ingress, corrosive gas damage, or installation in dirty environments, causing particles to affect performance — is not covered under this warranty.
- If PuREPower Unit is idle/ inoperative condition for more than 6 months can lead to void in warranty terms

11. Do's and Don'ts Do's

- Ensure installation is performed by authorized personnel
- Verify proper grounding and secure electrical connections.
- Use the app or cloud platform to monitor performance and receive alerts regularly.
- Ensure the unit is placed in a well-ventilated, dry area and away from direct sunlight to prevent overheating.
- Report faults immediately and ensure repairs are performed by authorized technicians
- If you plan to leave for a long time (≥ 30 days), you should comply with the following requirement to ensure that the SOC system of the battery is above 60% and the power switch is kept OFF. Keep in mind that the system should restart to charge the battery within 90 days.

Don'ts :

- Do not connect loads exceeding the rated capacity of the system.
- Do not attempt to repair or modify the unit without consulting authorized service personnel.
- Do not expose the unit to water, direct sunlight, corrosive chemicals, or physical shocks.
- Do not ignore fault alerts or fail to address them promptly.
- Do not remove the Wi-Fi module or disable the cloud monitoring setup.

12 . Instructions For Servicing

When the PuREPower is not functioning or for any query follow below instructions:

- Connect to the installer/dealer for immediate assistance or call toll-free No:1800 212 6440
- Our service team will guide you whether PuREPower to be sent back for repair or can be serviced near your location.
- The on-site visit charges are applicable as per the standards. In case of any warranty component replacements, only components are covered under warranty.
- PuREPower installation charges are applicable.

13. Disposal and Recycling Information

13.1 Environmentally Safe Disposal Practices

To minimize environmental impact and ensure the safe disposal of this PuREPower, users are advised not to dispose of the product with regular household waste. Instead, it should be handed over to an authorized electronic waste collection centre or returned to the manufacturer for proper recycling or disposal. Improper disposal may lead to environmental hazards or pose health risks.

This product is designed in compliance with applicable environmental standards and should be disposed of by local laws and regulations governing electronic waste.

13.2 Battery Disposal and Recycling

- If the PuREPower includes a built-in or external battery, please note:
- Batteries contain hazardous substances and must be disposed of carefully to avoid soil and water contamination.
- Do not incinerate, dismantle, or puncture the battery.
- Used batteries must be returned to the authorized collection centers or recyclers approved under the E-Waste (Management) Rules, 2022, as notified by the Ministry of Environment, Forest and Climate Change, Government of India.
- For lithium-ion batteries, users should consult local battery recycling programs or contact the manufacturer for take-back options.
- By disposing of this product and its components responsibly, you contribute to environmental conservation and support sustainable waste management practices.

14. Legal Disclaimers

14.1 Limitation of Liability

- The manufacturer and its authorized distributors shall not be liable for any direct, indirect, incidental, consequential, or special damages arising out of the use or inability to use this product, even if advised of the possibility of such damages. This includes, but is not limited to, damages for loss of profits, data, business interruption, or personal injury.
- The total liability of the manufacturer, whether in contract, tort, or otherwise, shall in no case exceed the purchase price of the product.

14.2. Misuse Disclaimer

This product is designed to be used strictly in accordance with the instructions provided in this manual. The manufacturer shall not be held responsible for any damage, injury, malfunction, or loss caused due to:

- Improper installation
- Unauthorized modification
- Operation under abnormal conditions (e.g., excessive load, extreme temperatures, or humidity)
- Use of incompatible or substandard accessories
- Failure to perform recommended maintenance

Any such use shall immediately void the warranty and the user shall bear all responsibility for resulting consequences.

14.3. Third-Party Component Exclusions

- This PuREPower may require integration with third-party components such as external batteries, solar panels, wiring, or circuit protection devices. The manufacturer disclaims all liability for performance issues, malfunctions, or damage resulting from the use of :
- Non-recommended or substandard third-party components
- Improper installation of such components
- Lack of compatibility or certification

The warranty shall not extend to any issues arising from the failure or malfunction of third-party accessories not supplied or recommended by the manufacturer

14.4. Governing Law and Jurisdiction

- This product and any disputes arising out of or in connection with its purchase, usage, warranty, or interpretation of this manual shall be governed by and construed in accordance with the laws of India.
- All disputes, claims, or proceedings arising out of this product shall be subject to the exclusive jurisdiction of the competent courts at Hyderabad, Telangana, and no other court shall have jurisdiction in such matters

15 . Technical datasheet

Model		PuREPower30.0
Input	Input Sources	3-Phase
	Rated Input Voltage	3 x 415 VAC
	Voltage Range	382-440 VAC
	Frequency	50 Hz/60 Hz (Auto sensing)
Output	Output Rating Power	30000W
	Output Voltage	415VAC ± 5%
	Waveform	Pure sine wave
	Transfer Time	10 ms
	Surge Power	60000VA
Grid-connected operation	Power Factor Range	>0.99
	Maximum conversion efficiency (DC/AC)	>97%
	Max. Continuous Discharging Current	90A X 7
Battery	Battery Voltage	54.3 V
	Max. Continuous charging Current	40A
SOLAR CHARGER & AC CHARGER	PV Charging Mode	Six MPPT
	MAX PV Input Power	6X5500W
	MPPT Tracking Range	90~ 450VDC
	MAX. PV Input Voltage	450VDC
	MAX. Input current	6X 18 A
	MAX AC/ PV Charging Current	450A
Display	LCD interface	Operating mode/load/etc.
General Data	Dimension, W x D x H (mm)	850 (W) x 650 (D) x1550 (H)
	Net Weight (kg)	460 ±10 Kgs
	Cooling concept	Advanced Nano PCM
	Communication Interface	BMS, Dry-contact,CAN, Bluetooth,Wifi,Al Cloud

16. PuREPower WARRANTY REGISTRATION CARD

CUSTOMER NAME: _____

ADDRESS 1: _____

CITY _____

STATE _____

PIN CODE _____

MOBILE NO: +91 _____

MAIL ID: _____

PuREPower MODEL : _____ **PuREPower S.NO:** _____

SOLD ON: DD _____ **MM** _____ **YY** _____ **DEALER CODE:** _____

STAMP & SIGNATURE DEALER

CUSTOMER SIGNATURE

17. QR codes for PuREPower Installation Guidelines



For Installation Videos



For Safety Protocol

After completing the installation of PuREPower, scan the below provided QR code and complete all the mandatory steps for successful installation and warranty registration.












For I&C Warranty registration links






Note: Filling out the form linked via the QR code is mandatory. Failure to provide installation details will result in the product's warranty being deemed null and void.

18. Display Setting

The LCD display information will be switched in turns by pressing "UP" or "DOWN" key. The selectable information is switched as below order: input voltage, input frequency, PV voltage, charging current, battery voltage, output voltage, output frequency, load percentage, load in Watt, load in VA, load in Watt, DC discharging current, main board firmware version and SCC firmware version.




Select item	LCD display
Input voltage and output voltage (Default Display Screen)	<p>Input Voltage=230V, output voltage=230V</p> 
Input frequency and output frequency	<p>Input frequency=50.0Hz, output frequency=50.0Hz</p> 
Battery voltage and output voltage	<p>Battery Voltage=48.0V, output voltage=230V</p> 
Battery voltage and load percentage	<p>Battery Voltage=48.0V, load percentage 68%</p> 




Battery voltage and load in VA	Battery Voltage=48.0V, load in VA=1.08kVA 
Battery voltage and load in Watt	Battery Voltage=48.0V, load in Watt=1.88kW 
PV1 voltage and PV1 charger power	PV1 Voltage=360V, charging power=1.58kW 
Charger current and DC discharging current	Charging current=30A, discharging current=0A 
PV energy generated today	Today energy = 6.3kWh 


PV energy generated this month	This month energy = 358kWh. 
PV energy generated this year	This year energy = 8.32MWh 
PV energy generated totally	Total energy = 13.9MWh 
Real date	Real date Nov 28, 2016. 
Real time	Real time 13: 20. 

Main board firmware version	Version 00001.00

Operating Mode Description

Operating mode	Behaviors	LCD display
Standby mode Note: *Standby mode: The inverter is not turned on yet but at this time, the inverter can charge battery without AC output. *Power swing mode: If enabled, the output of inverter will be off when connected load is pretty low or not detected.	No output power, solar or utility charger available	    
Line mode	Output power from utility. Charger available	 

	Output power from utility. Charger available	PV energy, battery power and utility provide power to load. 
Line mode	Output power from utility. Charger available	PV energy and utility charge battery, and utility provides power to load. 
		PV energy charges battery, utility and PV energy provide power to the load. 
		PV energy charges battery, PV energy provides power to the load and feeds remaining energy to the grid. 
		PV energy charges battery, PV energy provides power to the load and feeds remaining energy to the grid. 
Battery mode	Output power from battery or PV	PV energy and battery energy supply power to the load. 
		Battery provides power to the load. 
Only PV mode	Output power from PV	PV provides power to the load. 



PuR Energy Limited

H. No 10-38/2, Survey no 424/AA3, Beside Arya College of Pharmacy Near IIT
Hyderabad, Kandi Village, Sangareddy, Pin Code: 502285 Customer
Care: 1800 212 6440